

OBS!

Dette produktet krever et «Sim kort» som skal sitte i enheten. Sim kortet må være uten pinkode. For å fjerne pinkoden selv, sett simkortet inn i din telefon. Gå til telefoninnstillinger/simkortinnstillinger og deaktiverer sim-pin kode.

Steg 1: Åpne forpakningen, ta ut produktet fra emballasjen.

Steg 2: Sett inn Sim kortet, **PS: dette passer bare en vei.**

Steg 3: Sett i strømadapteret.

Steg 4: Ta frem mobiltelefonen/pc din og gå til wifi innstillinger. Deretter velg trådløst nettverk «**WI-TEK_XXXX**» Tast så passord: «**88888888**».

Steg 5: Åpne nettleser og skriv inn følgende adresse «**192.168.1.88**».

Steg 6: Skriv inn brukernavn og passord (brukernavn:admin)(passord:admin).

Steg 7: Trykk «**next**» på første bilde

Steg 8: velg «**4G mode**» deretter trykk next

Select system mode

Please choose to use the 4G routing mode or traffic card or connect the cable to access to Internet, according to your situation.

- 4G mode
 Router mode
 AP mode

Exit Wizard

Back

Next

Steg 9: Her kan du endre WIFI-navn og WIFI-passord, hvis ønskelig.

WiFi

configures the basic configuration of the wireless network. For detailed configuration, manage the WLAN configuration of the wireless configuration.

WiFi Enabled

WiFi name

Encryption

WiFi password

Exit Wizard

Back

Finish



Steg 10: Gratulerer du er nå satt opp din nye 4G ruter 😊